


How to Measure:

Hinged Cushions

All our measurements are width x length x height (thickness)



Hinge Cushion

When measuring a hinged cushion, it is important to make sure you are getting the correct back length as well as seat length.

The width of the cushion is obtained by measuring from side to side at widest point.

Measure from the top of the cushion to the hinge point to obtain back length.

Measure from the hinge point to the front edge of the cushion to obtain the correct seat length.

Measure height (thickness) from center at highest point.

Back length + Seat Length = Total cushion length

*Cushion thickness varies on type of furniture as well as personal preference

Chaise Lounge Cushion

When measuring a lounge cushion, it is important to make sure you are getting the correct back length as well as seat length.

Measure from the top of the cushion to the hinge point to obtain back length.


Measure from the hinge point to the front edge of the cushion to obtain correct seat length.

The width of the cushion is obtained by measuring from side to side at widest point.

Measure height (thickness) at center from highest point.

Back Length + Seat length = Total cushion length

It is best to lay cushion flat to get overall length.



Knife/French Edge Cushion

Measure from the top of the cushion to the hinge point to obtain back length.

Measure from the hinge point to the front edge of the cushion to obtain correct seat length.

The width of the cushion is obtained by measuring from side to side at widest point.

Back length + Seat length = Total cushion length

Measure height (thickness) from center at highest point.

*Cushion height (thickness) varies on type of furniture as well as personal preference

