


How to Measure:

Bench, Wicker and Euro Style

All our measurements are width x length x height (thickness)

Swing/Bench/Love Seat Cushion



When measuring a bench cushion, it is important to make sure you are getting the correct seat width as well as seat length (depth).

Measure from the left to the right at the back of the seat and the front of the seat to account for any variance.

Measure from the top to the bottom of the cushion. Measure height (thickness) at center from highest point.

*Cushion thickness varies on type of furniture as well as personal preference

Tufted Cushion

When measuring a tufted cushion, it is important to consider the height (loft) of the cushion to make sure it will fit your preferences.


Measure from highest point of thickness.

Tufted cushions may have different measurements from back to front of cushion.

Measure back from left to right and front from left to right.

Measure height (thickness) from center at highest point.

The width of the cushion is obtained by measuring from side to side at widest point.



Euro Style Cushion

When measuring a euro style cushion, it is important to note the tapering that occurs from the top of the seat back to the base of the seat back.

Measure height (thickness) from center at highest point.

Also note that the top stitching in the euro style will cause the cushion to gather in certain areas.

*For the Euro style we measure the widest area of the cushion.

